

# ADCRAFT®



## CK-2 Snack Oven

**This manual contains important information regarding your *Admiral Craft* unit. Please read this manual thoroughly prior to equipment set-up, operation and maintenance. Failure to comply with regular maintenance guidelines outlined in this manual may void the warranty. **MUST READ!!!****

## WARNINGS

- Do not touch any hot surfaces
- Do not cook oversized foods
- Do not store items on top of the unit
- Do not stack ovens
- Do not cook greasy foods that may cause damage to the coils
- Plug only into a 3-hole grounded electrical outlet
- Do not plug or unplug unit with wet hands
- Do not immerse unit, cord or plug in liquid at any time
- Unplug cord from outlet when not in use and before cleaning
- Do not operate unattended
- Do not use this unit for anything other than intended use
- Do not use outdoors
- Always use on a firm, dry and level surface at least 12" from walls or any other obstruction
- Do not use if unit has a damaged cord or plug, in the event the appliance malfunctions, or has been damaged in any manner
- Keep children and animals away from unit
- Any incorrect installation, alterations, adjustments and/or improper maintenance can lead to property loss and injury. All repairs should be done by authorized professionals only
- Ensure that the designated power supply is adequate for continual usage and the voltage is correct
- Do not open or remove cover of the oven as this will void the warranty

## TO ASSEMBLE

1. Ensure that there is at least 6 inches of clearance on all sides, including top and back of the unit.
2. Unit should be installed on a flat sturdy surface
3. Be sure that the unit is properly grounded to minimize shock or fire hazard.
4. Line up handle and panel together. Be sure that the handle will flip upwards.
5. Insert grill by inserting hook into oval opening on the panel. The hook should face upwards when installing.
6. Place the washer on the bolt and insert into the top round hole through the handle and panel.
7. Secure tightly with the screw from behind the panel.

*\*Improper assembly of the flip up handle to the grill could cause the grill to turn or fall off when moving product, possibly causing injury or burns.*


## TO USE

1. Oven requires no preheating.
2. Set the desired cook time by turning the knob of the timer switch.
3. Maintain constant supervision of oven while in use.
4. Caution should be used when removing food from the oven. Oven mitts or protective gear should be used to avoid the hot panel.
5. Unplug oven when not in use.

**CLEANING – NOTE:** To maintain cleanliness and increase service life, the brewer should be cleaned daily. Do not immerse the unit in water or any other liquid. If liquid enters the electrical compartment it may cause a short circuit or electrical shock

1. Allow unit to completely cool before cleaning.
2. Disconnect the cord from the outlet.
3. Slide out the crumb tray and remove any soil.
4. Wipe the crumb tray with a damp cloth.
5. Return the crumb tray to its proper position.
6. Wipe the outside of the unit with a damp cloth, then wipe dry.
7. Use caution while cleaning as there may be sharp edges.
8. To avoid damage, do not use abrasive cleaners or scouring pads.
9. If soap or chemical cleaners are used, be sure they are completely rinsed away with clear water immediately after cleaning. Chemical residue could damage or corrode the surfaces of the unit.

Snack Oven CK-2  
Circuit Diagram



VER8011

# CK-2 Parts Diagram

