Boning Knives



24003 SG131-6PCP 6" narrow curved boning knife 24003B SG131-6B-PCP 6" nar. curved boning knife, black



24013 SG136PCP 24013B SG136B-PCP

6" wide boning knife (NSF.) 6" wide boning knife, black



24033 SG136F-PCP 24033B SG136FB-PCP

24023 SG136N-PCP 24023B SG136NB-PCP

6" flexible boning knife 6" flexible boning knife, black 6" narrow boning knife (NSF)

6" narrow boning knife, black



11103 **P152HG** 31/4" clip point deboning knife



3½" utility/deboning knife 11123 **P154HG** 41/2" utility/deboning knife



11133 P155WHG 11143 **P156HG**

5" wide utility/deboning knife 6" hollow ground deboning knife

Bread Knives



24223 SG162-8SC-PCP 24223B SG162-8SCB-PCP 8" scalloped bread knife (NSE) 8" scalloped bread knife, black handle

Bread Knives



24423 SG163-9SC-PCP

24423B SG163-9SCB-PCP

9" scalloped offset sandwich knife 9" scalloped offset sandwich knife, black



24383 SG147-10SC-PCP 24383B SG147-10SCB-PCP

10" scalloped bread knife 10" scalloped bread knife,



24243 SG140-12SC-PCP 24243B SG140-12SCB-PCP 12" scalloped slicer

12" scalloped slicer, black

Chef/Cook's Knives

The Chef's/Cook's knife has more uses than any other one knife in the kitchen. The deep choil protects the knuckles when dicing or mincing. This knife is used in a rocking motion from the point back to the choil. The Chef's/Cook's knife is useful for light chopping, dicing, mincing, or slicing fruits, vegetables, and other ingredients.



DETER

24163 SG145-10PCP 24163B SG145-10B-PCP

24173 SG145-12PCP 24173B SG145-12B-PCP

10" cook's knife 10" cook's knife, black 12" cook's knife 12" cook's knife, black

