EQUIPMENT CLEANING

Oven & Grill Brushes

• Wire brushes and stainless steel metal scrapers make quick and easy removal of heavy carbon deposits, rust and burned-on food build up

Broiler Master

The best grill brush available and master of all grill cleaning tools. Rust-proof bristles are embedded in a rugged specially treated hardwood block for long-lasting cleaning power.



Double Broiler King 40294

• Sturdy construction with two heads featuring carbon steel flat bristles on one side and carbon steel wire bristles on the other; bolted together on a heavy hardwood handle for very heavy use

Oven Brush 41520 & 40291

 Crimped brass wire bristles and a full length stainless steel scraper for cleaning high-temperature stack ovens

Oven Brush 40293

 Crimped brass wire bristles and a full length aluminum scraper on a low-profile head for cleaning the narrow spaces inside pizza ovens

Pizza/BBQ Oven Brush 45772

• Steel wire bristles and permanent 39" hardwood handle

Oven & Grill Brush 363725

• Flat wire stainless steel bristles, oven scraper and 30" handle

45772

TOP SELLEF

40294

Color

Pack

40290



Standard(00)

Prod No Description

| Oven a | & Grill | Brushes |
|--------|---------|---------|
|--------|---------|---------|

| 40026 | 8.5" Broiler Master Brush, Carbon Steel Bristles with 30" Handle | 00 | 6 ea |
|--------|--|----|-------|
| 40290 | 8.5" Broiler Master Brush, Stainless Steel Bristles with 30" Handle | 00 | 6 ea |
| 40294 | 8" Double Broiler King, Carbon Steel Flat & Wire Bristles with 48" Handle | 00 | 2 ea |
| 41520 | 8.5" Oven Brush & Scraper, Brass Wire Bristles with 42" Handle | 00 | 1 ea |
| 40291 | 8.5" Oven Brush & Scraper, Brass Wire Bristles (Head Only) | 00 | 12 ea |
| 40293 | 10" Oven Brush & Scraper, Brass Wire Bristles (Head Only) | 00 | 12 ea |
| 45772 | 5.5" Pizza/BBQ Oven Brush, Carbon Steel Bristles and 33" Handle | 00 | 12 ea |
| 363725 | 8" Oven Brush with Scraper, Flat Wire Stainless Steel Bristles with 30" Handle | 00 | 1 ea |

NOTE: Equipment must be turned off prior to using Oven & Grill Brushes

*40291 & 40293 do not include handles; use with handle 40275 shown on page 295

40291

40293

363725