


Stainless Steel Food Mill USE AND CARE INSTRUCTIONS

CONTENTS

- 5 Qt food mill
- · Handle with attached blade
- 5 interchangeable graters
 - Round perforations: 2mm, 3mm, 4mm or 8mm
 - Rectangular perforation: 3 x 8.5mm



SAFETY

CAUTION: Be careful when handling, operating, and cleaning the food mill. Keep hands clear of blade when in use.

OPERATION

Wash before first use.

- 1. Place food mill on a container to collect the puree.
- 2. Place desired food into the mill.
- 3. Turn the food mill handle to process the food through the grater and into the container.

CLEANING

- 1. Disassemble the food mill.
- 2. Wash all food mill components in warm water with a mild soap solution. Avoid using abrasives.
- 3. Make sure components are completely dry before reassembling.

DISASSEMBLY AND ASSEMBLY

1. Remove handle with attached blade

Press down simultaneously on the hooked sides and rotate handle away from underneath the hooks. Lift out the handle with turning blade.

2. Remove grater from mill

Carefully remove grater by flipping over mill on a clean surface. Grater will fall out.

3. Insert grater into mill

Place desired grater, dome side up, in the bottom of the mill. Grater will sit on the bottom rim.

4. Attach turning handle to grater

Carefully insert the peg of the turning handle into the center hole of the grater.

5. Attach turning handle to hook

Line up the notches underneath the hooks in the interior of the mill's bowl. Press down simultaneously on the notched sides.

