



# Planetary Mixers Operating Instructions

BDPM-10 / BDPM-20 / BDPM-30



**STEP 1.** – Turn silver toggle switch ON



**STEP 2.** – Make sure that the bowl cage is closed completely



**STEP 3.** – The bowl lift handle must be in UP position  
(BDPM-30 - Rotate wheel to lift the bowl)



**STEP 4.** – Make sure the STOP button is OUT.  
Turn clockwise to release



**STEP 5.** – Timer must be put in infinite position or on certain amount of minutes.

(Not required for BDPM-10)

**Your mixer is now ready to use!**