



HOW TO CHARGE DURABLE MICROFIBER PADS

Charging microfiber prior to use helps to eliminate multiple trips to the sink to prepare cleaning solutions, and ensures the microfiber pads are properly moistened to cover one patient room, approximately 250 sq. ft.



1 **ADD** water and/or cleaning solution to the Charging Bucket. The bucket design features an internal measuring guide to prevent oversaturation. Each graduated step inside the Charging Bucket represents one quart, the ideal fluid level for five pads.



2 **PLACE** microfiber pads in the Charging Bucket with the white back side of the mops facing upward. Each bucket holds 20 microfiber pads.



3 **SECURE** leak-proof lid to the Charging Bucket by snapping the end and side tabs into place.



4 **FLIP** the Charging Bucket upside down and leave it **upside-down** for 5-10 minutes. This allows the cleaning solution to saturate all of the pads. The pads are now ready to use.

TIP

The HYGEN™ Charging Bucket integrates with the High-Security Cleaning Cart and High-Capacity Janitorial Cleaning Cart.

HYGEN™ CHARGING BUCKET SYSTEM

NO.	DESCRIPTION	COLOR	DIMENSIONS (L×W×H)	WEIGHT	CASE QTY
FGQ95088YEL	HYGEN™ Microfiber Charging Bucket	Yellow	23.88" × 9.50" × 13.63"	16.00 lb	3
FGQ41000BL00	HYGEN™ 18" Microfiber Wet Pad	Blue	20.50" × 5.20" × 0.50"	2.90 lb	12

CLEANING CARTS

NO.	DESCRIPTION	COLOR	DIMENSIONS (L×W×H)	WEIGHT	CASE QTY
FG9T7500BLA	High-Security Cleaning Cart	Black	48.25" × 22.00" × 53.50"	70.00 lb	1
1861427	Executive Series High-Security Cleaning Cart	Black	48.25" × 22.00" × 53.50"	70.00 lb	1
FG9T7300BLA	High-Capacity Janitorial Cleaning Cart with Bins	Black	48.25" × 22.00" × 44.00"	53.00 lb	1